

Targa® Rigid Impact Protection Radius Guide

For Products

Targa® Rigid Impact Protection Panels

Installing on a Radius

Targa® wallcovering has a minimum radius of 24" when formed in the field.

All of the material can be installed, following our standard installation instructions, using our mastic adhesive. Additional bracing, strapping, or other means of applying pressure inward, toward the column, may be necessary to keep in position, until mastic fully cures.

3M Fastbond Contact Adhesive may be used to eliminate the need for some strapping, until the adhesive cures. Follow the instructions on the adhesive and scuff the rear of the sheet to allow for better adhesion.

Questions?



Contact your Level Digital Wallcoverings [Sales Representative](#)



Visit findyourlevel.com for more information